

Keyboard Hot Keys

F1 to F7	Play Macros
Ctrl-Fn	Record Macros. Enter keystrokes. Ctrl-Z to conclude entry.
Alt-Fn	Delete Macro associated with Fn.
F8	Toggle TUNE mode on/off. Accessible only in RX or TX. (Not in Setup, or Macro Recording.)
Shft-F9	Turn on Beacon Mode. 'BCN' displayed.
Alt-F9	Turn off Beacon Mode.
F10	Toggle between RX and TX. (Not in Setup, or Macro Recording)
F11	Display "MyCall" from EEPROM.
F12	Toggle on/off a display of modem's current settings.
Ctrl-M	Record "MyCall" into EEPROM. Ctrl-Z to conclude entry.
Ctrl-T	Record "TheirCall" into RAM. Ctrl-Z to conclude entry.
Alt-M	Insert "MyCall" into a Macro.
Alt-T	Insert "TheirCall" into a Macro.
Ctrl-F	Save the current frequency into EEPROM so that it can be restored at the next power-up.
Alt-F	Retrieve the saved freq and makes it the current freq.
Ctrl-Tab	Display the current frequency (audio)
Ctrl-A	Enable AFC
Alt-A	Disable AFC
PgUp	Increase input gain (PGA)
PgDn	Decrease input gain (PGA)
Ctrl-L	Clear the text area of the LCD
Ctrl-K	Clear the keyboard buffer. While receiving, keystrokes are not displayed—this allows clearing the buffer, so that callsign may be entered, or re-entered in case you think that you have entered the wrong callsign.
Ctrl-B	Clears the internal buffers
Ctrl-Q	Inserts a TX-OFF control character in the TX buffer, or Macro.
Ctrl-S	Insert a TX-ON control character in the TX buffer, or Macro
Ctrl-O	Toggles the display backlight on and off.
Ctrl-U	Toggles REC mode on/off for recording text to USB drive.
Ctrl-N	Enter filename to be used for recording text to USB drive.
Ctrl-I	Enter free-form text to be recorded to USB drive.

USB-Related Hot Keys:

Ctrl-U:	Toggle REC mode on/off. (REC displayed on right edge of display.) REC mode is aborted if no flash device present in connector. If no USB card detected, the modem's piezo is beeped after 5 seconds and REC mode is aborted.
Ctrl-N:	Enter name for USB file to be recorded. Ctrl-Z to conclude entry. Standard 8.3 file names accepted. (E.g., "FD2008-2.txt")
Ctrl-I:	Insert text into recording file. Ctrl-Z to conclude entry. The USB file must already be open (Ctrl-U) for this to work. The recording file remains open for additional Rx or Tx text, until Ctrl-U pressed again to close the recording file.

Spectrum Cursor Tuning Rates:

Left: 1x: Left Arrow	Right: 1x: Right Arrow
2x: Down Arrow	2x: Up Arrow
5x: ALT + Left Arrow	5x: ALT+ Right Arrow
10x: ALT + Down Arrow	10x: ALT + Up Arrow

Config Menu:

Mode: BPSK, QPSK, QPSK/R
Squelch Threshold: 25, 50
CWID: On, Off
PGA Gain: x1, x5, x16, x32
Tune Increment: Single, Double
Battery Voltage
TX Audio Level

Save Config
Beacon Mode
PC Bootload
Flash Bootload
Exit

Recent Change Summary

- 1) USB Add-On card support
 The USB add-on card makes your NUE-PSK Digital Modem more useful with its ability to record QSO text (receive and transmit) to a USB flash memory stick for archival and remote printing. Use of the USB card requires v1.33 (or later) software containing new keyboard commands for controlling the card functions, plus an improved and consistent set of text editing commands. The USB card fits into the existing modem enclosure with minimal mods, and a replacement bottom chassis is available with pre-drilled holes for the connectors.
- 2) USB-specific keyboard hot keys added:
 Ctrl-U, Ctrl-N, Ctrl-I
- 3) Text entry made more intuitive and consistent ...
 - keystrokes made visible for all commands
 - specific keyboard hot keys entered before text
 - all text entry concluded with Ctrl-Z
 - text entry beyond buffer limits sounds the beeper
- 4) Beacon Mode has been added to allow repetitive automatic transmissions to be made for experimental far-field measurement tests.

Example Usage of Keyboard Hot Keys

- 1) Record MyCall to EEPROM ...
Ctrl-M n2apb Ctrl-Z
- 2) Record CQ sequence into F1 macro ...
Ctrl-F1 Ctrl-S cq cq cq de Alt-M Ctrl-Q Ctrl-Z
 Play the macro by pressing F1 and see ...
Tx comes on, "cq cq cq de n2apb", Tx turns off

Example Usage of Recording to USB Device

- 1) Power up modem (flash mem device not inserted)
- 2) Enter filename for file to be recorded ...
Ctrl-N FieldDay.txt Ctrl-Z
- 3) Plug in flash mem device, turn on REC mode to begin recording
Ctrl-U
 and see the USB LED blink fast.
- 4) Insert block of free form text to Flash filename ...
Ctrl-I Field Day 2008 QSO recordings Ctrl-Z
- 5) Tune around and find a station to call
- 6) Enter Tx mode per usual (F10) to call. Entered text is recorded to USB filename.
- 7) Enter Rx mode per usual (F10) to receive. Receive text is recorded to USB filename.
- 8) Insert free form text to USB file ...
Ctrl-I Time ending QSO is 2130 hrs. Ctrl-Z
- 9) Close USB file recording session ...
Ctrl-U
 and see the USB LED stop blinking and go solid on.
- 10) Remove Flash memory device for remote viewing, archival or printing.

For further information, including a full Operating Manual, visit www.nue-psk.com

An active discussion group is maintained on Yahoo Groups in the NUE-PSK section. Visit <http://groups.yahoo.com> to get started.

In case of questions or technical problems, please contact support@nue-psk.com