



D1 is wise to include, but not yet present on pcb

Normally closed switch inside J1. Opens when external supply is connected.

(Cut trace 'X' if 3.3V is not needed by programming adapter)

(data directions)

Rev A.17 03/07/08

NUE-PSK
 M. Cram, W8NUE
 G. Heron, N2APB